



Warranty Certificate Terms and Conditions

LOGIC warrants that their Products will be free from defects in material and workmanship. The warranty period is one (1) year for the products and three (3) months for the accessories which are part of the original package including the battery. The warranty period begins the date of purchase by the End-User who shall present an invoice or a purchase receipt when requiring warranty service otherwise the warranty period will begin from the date of manufacture of the product. LOGIC will repair a product without cost to the customer if it presents a manufacturing defect or defect in workmanship during the warranty period and if the defect occurred under normal conditions of use in accordance with the instructions and specifications stated in the user's manual.

For additional information about the terms and conditions of LOGIC's Limited Warranty or to obtain warranty service information, please visit the support section at: logicmobility.com

Certificado de Garantía Términos y Condiciones


LOGIC garantiza que sus productos estarán libres de defectos de materia prima y ensamblaje. El período de garantía es de un (1) año para los productos y de tres (3) meses para los accesorios que forman parte del paquete original incluyendo la batería. El usuario final deberá presentar una factura o un recibo de compra cuando exija el servicio de garantía, de lo contrario el período de garantía comenzará a partir de la fecha de fabricación del producto. LOGIC reparará un producto, sin costo para el cliente si presenta un defecto de fabricación o un defecto de ensamblaje durante el período de garantía y si el defecto se produjo en condiciones normales de uso de acuerdo con las instrucciones y especificaciones indicadas en el manual del usuario.

Para más detalles de la Garantía Limitada de LOGIC y para obtener información del servicio de garantía, por favor visite la sección de soporte en nuestro sitio web: logicmobility.com.

logicmobility.com

Made in China 


Copyright Swagtek, Inc. 2025



LOGIC

UNIVERSAL BT KEYBOARD FOR TABLET

QUICK GUIDE / GUÍA RÁPIDA



1.Feature

Thank you for choosing the Logic Bluetooth wireless keyboard. It has built in rechargeable polymeric lithium battery and charging indicator. The keyboard will enter into sleeping mode if there is no action in 10 minutes to prolong battery life.

2.Pairing Instruction


Before you can use this keyboard, it must be connected to your tablet or any compatible device. Once it has paired successfully, you do not need to re-connect it in future. Please connect the keyboard with your tablet according to the following instructions below.

Turn on the keyboard.


Press the "Connect" button to 3 seconds, the blue light blinks.

Open the Bluetooth from settings in your device and find the Logic BT Keyboard, then click and connect (Password free connection).


①




②



③



④



3.Hot Keys

Fn+ function keys, Press **Fn** and the blue keys as below

Desk/Exit	Previous	Lock Screen
Searching	Play/Pause	Language Switching
Select All	Next	
Copy	Volume -	Soft Keyboard Switch
Paste	Volume +	
Cut	Fn Funtion Key	

4.Indicator

Power LED: When the keyboard turns on, it flashes 1-2 seconds and then goes out automatically.

Charge LED: Its on while charging and goes out once the battery is full.

BT LED: It flashes when the keyboard is connecting and goes out after connected.


Caps LED: It on when switched to capital letters.

Charging Instruction

1.Please charge at least 6 hours when you first time use this keyboard. Next time when the battery is low, please at least charge 2 hours.

2.The red indicator flashes means the it is low battery and please charge it in time. It is charging when the red indicator flashes all the time.

3.Please connect the charging cable to the keyboard correctly as below.



Troubleshooting

If your keyboard doesn't work properly:

1. Please make sure that your device Bluetooth function is enabled.
2. The keyboard should be within 10 meters of the connected tablet or compatible device.
3. Keyboard built-in battery power is too low, please charge the keyboard.
4. If the keyboard is not connected or paired with the tablet after successful pairing, the text input delay or even typing letters appear in the process, please according to the following steps: delete all Bluetooth devices - restart the tablet again.

Specification

- 1) Frequency: 2.4GHz
- 2) Working Voltage: 3.7V DC
- 3) Working Current: <5mA
- 4) Standby current: 1.0mA
- 5) Sleeping current: <0.25mA
- 6) Working distance: 10 meters



1.Funciones

Gracias por elegir el teclado inalámbrico Bluetooth Logic. Lleva incorporada una batería de litio recargable y un indicador de carga. El teclado entrará en modo de descanso si no hay actividad durante 10 minutos, por lo siguiente tiene un bajo y larga duración de la batería.

2.Instrucciones de Conexión

Antes de utilizar este teclado, debe estar conectado a su tableta o algún otro dispositivo. Cuando se conecta satisfactoriamente, usted no necesitará re-conectarlo en el futuro. Por favor siga las siguientes instrucciones para conectar el teclado o su tableta.

Enciende el teclado.

Presione el botón de "Conector" por 3 segundos. lo luz azul parpadeo.

Abra lo configuración de Bluetooth en su tableta y encuentre el Bluetooth Keyboard. después presione conector (Conexión libre de contraseña).


①



②



③



④



3.Teclas Principales

Fn+ teclas de función, Presione **Fn** y la tecla azul como se muestra a continuación



4.Indicador

LED de Encendido: cuando el teclado se enciende, parpadea de 1 a 2 segundos y luego se apaga automáticamente.


LED de Carga: Se enciende mientras se carga y se apaga una vez que la batería está llena.

LED BT: parpadea cuando el teclado se está conectando y se apaga después de conectarlo.

LED Mayúsculas: Se enciende cuando se cambia a letras mayúsculas.

Instrucciones de carga

1. Cargue al menos 6 horas cuando use este teclado por primera vez. La próxima vez que la batería esté baja, cárguela al menos durante 2 horas.
2. El indicador rojo parpadea significa que la batería tiene poca carga y cárguela a tiempo. Se está cargando cuando el indicador rojo parpadea todo el tiempo.
3. Conecte el cable de carga al teclado correctamente como se muestra a continuación.



Solución de problemas

Si su teclado no funciona correctamente:

1. Asegúrese de que la función Bluetooth de su dispositivo esté habilitada.
2. El teclado debe estar a menos de 10 metros de la tableta o dispositivo compatible conectado.
3. La carga de la batería incorporada del teclado es demasiado baja; cargue el teclado.
4. Si el teclado no está conectado o emparejado con la tableta después del emparejamiento exitoso, aparece un retraso en la entrada de texto o incluso escribir letras en el proceso, siga los siguientes pasos: elimine todos los dispositivos Bluetooth - reinicie la tableta nuevamente.

Especificaciones

- 1) Frecuencia: 2.4GHz
- 2) Voltaje: 3.7V DC
- 3) Corriente en función: <5mA
- 4) Corriente en modo espera: 1.0mA
- 5) Corriente en modo descanso: <0.25mA
- 6) Rango de alcance: 10 metros