



Warranty Certificate Terms and Conditions

LOGIC warrants that their Products will be free from defects in material and workmanship. The warranty period is one (1) year for the products and three (3) months for the accessories which are part of the original package including the battery. The warranty period begins the date of purchase by the End-User who shall present an invoice or a purchase receipt when requiring warranty service otherwise the warranty period will begin from the date of manufacture of the product. LOGIC will repair a product without cost to the customer if it presents a manufacturing defect or defect in workmanship during the warranty period and if the defect occurred under normal conditions of use in accordance with the instructions and specifications stated in the user's manual.

For additional information about the terms and conditions of LOGIC's Limited Warranty or to obtain warranty service information, please visit the support section at: logicmobility.com

Certificado da Garantia Termos e Condições

A LOGIC garante que seus produtos estarão livres de defeitos de matéria-prima e montagem.

O período de garantia é de um (1) ano para os produtos e de três (3) meses para os acessórios que fazem parte da embalagem original, incluindo a bateria.

O usuário final deverá apresentar uma nota fiscal ou comprovante de compra ao solicitar o serviço de garantia. Caso contrário, o período de garantia será considerado a partir da data de fabricação do produto.


A LOGIC reparará o produto sem custo para o cliente caso apresente defeito de fabricação ou de montagem durante o período de garantia, desde que o defeito tenha ocorrido em condições normais de uso, de acordo com as instruções e especificações indicadas no manual do usuário.

Para mais detalhes sobre a Garantia Limitada da LOGIC e para obter informações sobre o serviço de garantia, visite a seção de suporte em nosso site: logicmobility.com.

logicmobility.com

Made in China   


Copyright Swagtek, Inc. 2026



LOGIC

UNIVERSAL BT KEYBOARD FOR TABLET

QUICK GUIDE / GUIA RÁPIDO




1.Feature

Thank you for choosing the Logic Bluetooth wireless keyboard. It has built in rechargeable polymeric lithium battery and charging indicator. The keyboard will enter into sleeping mode if there is no action in 10 minutes to prolong battery life.


2.Pairing Instruction

Before you can use this keyboard, it must be connected to your tablet or any compatible device. Once it has paired successfully, you do not need to re-connect it in future. Please connect the keyboard with your tablet according to the following instructions below.


- Turn on the keyboard.
- Press the "Connect" button to 3 seconds, the blue light blinks.
- Open the Bluetooth from settings in your device and find the Logic BT Keyboard, then click and connect (Password free connection).



③



④



3.Hot Keys

Fn+ function keys, Press **Fn** and the blue keys as below

Desk/Exit	Previous	Lock Screen
Searching	Play/Pause	Language Switching
Select All	Next	Soft Keyboard Switch
Copy	Volume -	
Paste	Volume +	
Cut	Fn Funtion Key	

4.Indicator

Power LED: When the keyboard turns on, it flashes 1-2 seconds and then goes out automatically.

Charge LED: Its on while charging and goes out once the battery is full.

BT LED: It flashes when the keyboard is connecting and goes out after connected.


Caps LED: It on when switched to capital letters.

Charging Instruction

1.Please charge at least 6 hours when you first time use this keyboard. Next time when the battery is low, please at least charge 2 hours.

2.The red indicator flashes means the it is low battery and please charge it in time. It is charging when the red indicator flashes all the time.

3.Please connect the charging cable to the keyboard correctly as below.



PR


Troubleshooting

If your keyboard doesn't work properly:

1. Please make sure that your device Bluetooth function is enabled.
2. The keyboard should be within 10 meters of the connected tablet or compatible device.
3. Keyboard built-in battery power is too low, please charge the keyboard.
4. If the keyboard is not connected or paired with the tablet after successful pairing, the text input delay or even typing letters appear in the process, please according to the following steps: delete all Bluetooth devices - restart the tablet again.

Specification

- 1) Frequency: 2.4GHz
- 2) Working Voltage: 3.7V DC
- 3) Working Current: <5mA
- 4) Standby current: 1.0mA
- 5) Sleeping current: <0.25mA
- 6) Working distance: 10 meters






1. Funções

Obrigado por escolher o teclado sem fio Bluetooth Logic. Ele possui uma bateria de lítio recarregável integrada e um indicador de carga. O teclado entrará no modo de repouso se não houver atividade durante 10 minutos, proporcionando baixo consumo de energia e maior duração da bateria.

2. Instruções de Conexão

Antes de utilizar este teclado, ele deve ser conectado ao seu tablet ou a outro dispositivo. Após ser conectado com sucesso, não será necessário conectá-lo novamente no futuro. Siga as instruções abaixo para conectar o teclado ao seu tablet:

- Ligue o teclado.
- Pressione o botão "Conectar" por 3 segundos. A luz azul começará a piscar.
- Abra as configurações de Bluetooth no seu tablet e localize "Bluetooth Keyboard". Em seguida, selecione-o para realizar a conexão (sem necessidade de senha).



3. Teclas Principais

Fn+ teclas de função: pressione a tecla **Fn** e a tecla azul, conforme mostrado abaixo.



4. Indicadores

LED de Ligado: quando o teclado é ligado, o LED pisca por 1 a 2 segundos e depois se apaga automaticamente.


LED de Carregamento: permanece aceso durante o carregamento e se apaga quando a bateria está totalmente carregada.

LED Bluetooth: pisca enquanto o teclado está se conectando e se apaga após a conexão ser estabelecida.

LED de Letras Maiúsculas: acende quando a função de letras maiúsculas está ativada.

Instruções de Carregamento

1. Carregue o teclado por pelo menos 6 horas antes de utilizá-lo pela primeira vez. Nas próximas vezes, quando a bateria estiver com pouca carga, carregue-a por pelo menos 2 horas.
2. Quando o indicador vermelho piscar, significa que a bateria está com pouca carga e deve ser recarregada. Durante o carregamento, o indicador vermelho permanecerá piscando.
3. Conecte corretamente o cabo de carregamento ao teclado, conforme mostrado abaixo.



Solução de Problemas

Se o teclado não estiver funcionando corretamente:

1. Certifique-se de que a função Bluetooth do seu dispositivo esteja ativada.
2. O teclado deve estar a menos de 10 metros do tablet ou do dispositivo compatível conectado.
3. Se a carga da bateria interna do teclado estiver muito baixa, recarregue o teclado.
4. Se o teclado não estiver conectado ou emparelhado com o tablet após um emparelhamento bem-sucedido, ou se houver atraso na digitação ou problemas ao inserir letras, siga estas etapas: remova todos os dispositivos Bluetooth emparelhados e reinicie o tablet.

Especificações

- 1) Frequência: 2,4 GHz
- 2) Tensão: 3,7 V DC
- 3) Corrente em funcionamento: < 5 mA
- 4) Corrente em modo de espera: 1,0 mA
- 5) Corrente em modo de repouso: < 0,25 mA
- 6) Alcance: 10 metros